






S. N.	Part Code	Parts Name
1	41001	Outer Flange
2	41002	Grinding wheel
3	41003	Inner Flange
4	41004	Wheel cover
5	41005	Output shaft
6	41006	Dust cover
7	41007	Screw M4*14
8	41008	Bearing holder
9	4101009A	Bearing 6201RS Z3
10	4101110A	Spring ring 32
11	4101211A	Big gear
12	4101312A	HK0808 needle bearing
13	4101413A	Self-locking pin
14	4101514A	Pinion
15	4101615A	M6 Nut
16	4101716A	Screw
17	4101817A	Self-locking spring
18	4101918A	Self-locking cap
19	4102019A	Gear cover
20	4102120A	O-ring Ø21.5*1.8
21	4102221A	608 Bearing
22	4102322A	Spring ring 22
23	4102423A	Dust cover

S. N.	Part Code	Parts Name
24	4102524A	Armature
25	4102625A	Ring
26	4102726A	Washer $\phi 7 \times \phi 14 \times 0.3$
27	4102827A	Bearing
28	4102928A	Bearing sleeve
29	4103029A	Fad Guid
30	4103130A	Screw
31	4103231A	Stator
32	4103332A	Screw
33	4103433A	Carbon brush
34	4103534A	Carbon brush holder
35	4103635A	Coil spring
36	41036A	Switch
37	41037A	Motor housing
38	41038A	Switch rod
39	41039A	Pushing block
40	41040	Screw
41	4103941A	Wire plate
42	41042	Cord guard
43	41043	Back cover
44	41044	power cord
45	41045	Screw
46	41046	Wrench