






S. N.	Part Code	Parts Name
1	41150001	Bearing Sleeve
2	41150002	Bearing 626
3	41150003	Dust-proof Cushion
4	41150004	Armature
5	41150005	Center Cover
6	41150006	Bearing 608
7	41150007	Screw
8	41150008	Pinion
9	41150009	Head
10	41150010	Self-lock cap
11	41150011	Self-locking pin Spring
12	41150012	Screw
13	41150013	Side Handle
14	41150014	Gear
15	41150015	Bearing Cover
16	41150016	Bearing 6001
17	41150017	FRONT cover
18	41150018	SCREW
19	41150019	wheel Guard
20	41150020	Dust Cap
21	41150021	Output Shaft
22	41150022	Nether Pressing Plate

S. N.	Part Code	Parts Name
23	41150023	Top Pressing Plate
24	41150024	Screw
25	41150025	Screw
26	41150026	Bearing Hk0709
27	41150027	Self-lock pin
28	41150028	Nut
29	41150029	Screw
30	41150030	Stator
31	41150031	Casing
32	41150032	Switch Base
33	41150033	Cable Pressing Plate
34	41150034	Screw
35	41150035	Name Plate
36	41150036	Switch Base
37	41150037	Carbon Brush Holder
38	41150038	Carbon Brush
39	41150039	Carbon Brush Holder Cap
40	41150040	Cable Sleeve
41	41150041	Cable
42	41150042	Back Cover
43	41150043	Screw