






S. N.	Part Code	Parts Name
1	105001	Screw M5X20-LH
2	105002	Chuck
3	105003	Output shaft
4	105004	Semicircular Key 3X3.7X10
5	105005	Deep groove ball bearing 6001-2RS
6	105006	Circlip 12
7	105007	gear
8	105008	Circlip 10
9	105009	Deep groove ball bearing 698zz
10	105010	Deep groove ball bearing 608-2R
11	105011	Srotor
12	105012	Deep groove ball bearing 607-2RS
13	105013	stator
14	105014	Motor housing
15	105015	Cross pan head screw St4x16
16	105016	Lable
17	105017	Brush holder
18	105018	Carbon brush
19	105019	Brush holder cover
20	105020	switch
21	105021	Capacitance 0.22uf
22	105022	sheath
23	105023	Cable 2x0.5mmx2mx ϕ 7 (bright)
24	105024	Plastic cover
25	105025	key