






S. N.	Part Code	Parts Name
1	5190001	Outer Hex Bolt M8x18-lh
2	5190002	Outer Flange
3	5190003	Inner Flange
4	5190004	Inner Hex Screw M5x18
5	5190005	Oil Sealing
6	5190006	Gear Washer
7	5190007	Spindle
8	5190008	6002 Bearing
9	5190009	Internal Retaining
		Ringφ32
10	5190010	Big Gear
11	5190011	606 Bearing
12	5190012	Front Cover
13	5190013	Gearcase
14	5190014	Nut M7
15	5190015	Pinion
16	5190016	629 Bearing
17	5190017	O Ring Φ29*φ26*3
18	5190018	Washer Φ9*φ18*0.5
19	5190019	Armature
20	5190020	Baffle Plate
21	5190021	Shoe
22	5190022	Screw M5x40
23	5190023	Nut M5
24	5190024	Screw M6x8
25	5190025	Washer Φ6*φ12*1.5
26	5190026	Depth Knob
27	5190027	Screw M4x10

S. N.	Part Code	Parts Name
28	5190028	Screw St6x65a
29	5190029	Stator
30	5190030	Dust Proof Ring
31	5190031	608 Bearing
32	5190032	Iron Bearing Sleeve
33	5190033	Switch Cap
34	5190034	Cord Sleeve
35	5190035	Switch Sleeve
36	5190036	Screw St4x14a
37	5190037	Switch
38	5190038	Cord Pressplate
39	5190039	Motor Housing
40	5190040	Brush Cap
41	5190041	Carbon Brush
42	5190042	Brush Holder
43	5190043	Screw St4x16f
44	5190044	Rear Cover
45	5190045	Screw M5x35
46	5190046	Screw St4x12f
47	5190047	Power Cord
48	5190048	T Spanner
49	5190049	Water Tap
50	5190050	Water Nozzle
51	5190051	Wrench
52	5190052	Base Plate for Wood