






S. N.	Part Code	Parts Name
1	30522001	Hex Screw M8×20
2	30522002	Outer Flange
3	30522003	Inner Flange
4	30522004	Spindle
5	30522005	Woodruf Key 4#
6	30522006	Hex Screw M5×14
7	30522007	Spring Washerφ5
8	30522008	Flat Washerφ5
9	30522009	Front Cover
10	30522010	Ball Bearing 6203
11	30522011	Gear
12	30522012	Shaft Circlip
13	30522013	Bearing 6001
14	30522014	Aluminum Blade Cover
15	30522015	Bearing 6202
16	30522016	Self-lock Spring
17	30522017	Self Lock
18	30522018	Rotor
19	30522019	Bearing 6000
20	30522020	Windshield
21	30522021	Hex Screw St5x65a
22	30522022	Stator
23	30522023	Motor Housing
24	30522024	Hex Screw M5x55
25	30522025	Rear Cover
26	30522026	Hex Screw St4x14
27	30522027	Brush Holder Cap
28	30522028	Carbon Brush
29	30522029	Brush Holder
30	30522030	Down Handle
31	30522031	Switch
32	30522032	Upper Handle
33	30522033	Hex Screw M5x35
34	30522034	Hex Screw St5x35a

S. N.	Part Code	Parts Name
35	30522035	Right Assistant Handle
36	30522036	Left Assistant Handle
37	30522037	Pressing Line Plate
38	30522038	Cable Sheath
39	30522039	Cable
40	30522040	Screw M6x12
41	30522041	Safety Guard
42	30522042	Torsional Spring
43	30522043	Hex Screw M6x10
44	30522044	Safety Guard Cover
45	30522045	Locknut M6
46	30522046	Guide Dust Piece
47	30522047	Hex Screw M5x16
48	30522048	Dust Cover
49	30522049	Plate
50	30522050	Ruler
51	30522051	Pointer
52	30522052	Plate Cover
53	30522053	Hex Screw M4x12
54	30522054	Flat Washerφ8
55	30522055	Hex Screw M8x30
56	30522056	Nut M8
57	30522057	Hex Screw M8x20
58	30522058	Hex Screw M8x20
59	30522059	Locknut M16
60	30522060	Flat Washerφ16
61	30522061	Hex Screw M8x40
62	30522062	Rotary Support
63	30522063	Rubber Ring
64	30522064	Rubber Wheel Core
65	30522065	Hex Screw M8x20
66	30522066	Hex Screw M6x8
67	30522067	Connecting Rod
68	30522068	Big Torsional Spring



S. N.	Part Code	Parts Name
69	30522069	Fulcrum Pin
70	30522070	Screw M10
71	30522071	Flat Washerφ10
72	30522072	Gland Nut
73	30522073	Locking Wrench
74	30522074	Locking Wrench Spring
75	30522075	Flat Washerφ18xφ5x1
76	30522076	Trim
77	30522077	Screw M8x45
78	30522078	Lock Pin Spring
79	30522079	Lock Pin
80	30522080	Round Pin Φ2.5x16
81	30522081	Lock Pin M6
82	30522082	Plate Handle
83	30522083	Plate Handle Cover
84	30522084	Hex Screw M5x50
85	30522085	Fixed Block Shrapnel
86	30522086	Fixed Block
87	30522087	Hex Screw M5x18
88	30522088	Locknut M5
89	30522089	Trigger Shrapnel
90	30522090	Tilt Angle Trigger
91	30522091	Nut M10
92	30522092	Hex Screw M6x35
93	30522093	Cross Bar
94	30522094	Spring Washerφ8
95	30522095	Hex Screw M8x35
96	30522096	Assitant Cross Bar

S. N.	Part Code	Parts Name
97	30522097	Assitant Cross Bar Fixed Block
98	30522098	Assitant Cross Bar Trigger
99	30522099	Nut M6
100	30522100	Flat Washerφ6
101	30522101	Pedestal
102	30522102	Locknut M10
103	30522103	Hex Screw M5x12
104	30522104	Aluminum Side Cover
105	30522105	Locknut M5
106	30522106	Block Rubber [®]
107	30522107	Bearing Cover
108	30522108	Hex Screw St4x16
109	30522109	Handle Cover
110	30522110	Hex Screw M5x18
111	30522111	Pressing Plate
112	30522112	Clamp
113	30522113	Hex Screw M6x14
114	30522114	Pin
115	30522115	Screw Rod Handle Wheel
116	30522116	Screw Rod M12x115
117	30522117	Screw Rod Handle Wheel
118	30522118	Cover spanner
119	30522119	Dust Bag
120	30522120	Locknut
121	30522121	Ring Φ5
122	30522122	Rubber Wheel
123	30522123	Bush