






S. N.	Part Code	Parts Name
1	180001	Crosshed thread screw
2	180002	Transparent cover
3	180003	Transparent cover plate
4	180004	Adjusting screw
5	180005	Fixed iron
6	180006	Positioning iron
7	180007	Butterfly screws
8	180008	Carriage bolts
9	180009	Carriage bolts
10	180010	Crosshed thread screw
11	180011	Steel sleeve
12	180012	Adjusting screw
13	180013	Aluminium block
14	180014	Aluminium block
15	180015	Metal plate
16	180016	Crosshed thread screw
17	180017	Needle rolling adjusting screw
18	180018	Adjusting screw
19	180019	Adjust the needle
20	180020	Needle rolling adjusting screw
21	180021	External hex screw22

S. N.	Part Code	Parts Name
22	180022	Chuck
23	180023	Housing
24	180024	Bearing
25	180025	Retaining ring
26	180026	Armature
27	180027	Dust-proof plate
28	180028	Bearing
29	180029	Bearing bush
30	180030	Crosshed thread screw
31	180031	Stator
32	180032	Middle cover [®]
33	180033	Carbon brush
34	180034	Carbon brush holder
35	180035	Carbon brush cover
36	180036	Tension disc
37	180037	Crosshed thread screw
38	180038	Switch
39	180039	Cable protector
40	180040	Rear cowl
41	180041	Cable and plug
42	180042	Crosshed thread screw