






S. N.	Part Code	Parts Name
1	16600001	M6 Screw
2	16600002	Plastic cover
3	16600003	4.2*35 Opening pin
4	16600004	Upper adjusting hand wheel
5	16600005	Ø18.2*Ø21.8*1 Stainless gasket
6	16600006	Ø18.8*1.7*25.8H*4 Spring
7	16600007	Ø18*Ø30*3 Damping gasket
8	16600008	Upper press wheel adjusting nut
9	16600009	Upper press wheel adjusting screw
10	16600010	M8 Screw nut
11	16600011	Press the wheel and the plate
12	16600012	Upper press wheel
13	16600013	Ø18*Ø32*7 Framework oil seal
14	16600014	Ø12*Ø18*10 Oil seal iron sleeve
15	16600015	Ø32 Inside spring pliers
16	16600016	6201 Bearing
17	16600017	Upper press wheel drive shaft
18	16600018	6200 Bearing
19	16600019	Upper press wheel retainer right
20	16600020	Ø4.5*Ø13.8*1.5 Gasket
21	16600021	4*14 Three-piece set of screws
22	16600022	Ø8*Ø10*25 Movable pin

S. N.	Part Code	Parts Name
		iron sleeve
23	16600023	Movable pin
24	16600024	Ø18.2*Ø21.8*1 Stainless gasket
25	16600025	M5*16 Screw
26	16600026	M6*30 Screw
27	16600027	M5 Screw
28	16600028	Plastic roller
29	16600029	Upper protective cover
30	16600030	Upper press wheel retainer left
31	16600031	M5 Screw
32	16600032	Plastic roller
33	16600033	Plastic subcover
34	16600034	Tension spring
35	16600035	M4*10 Screw
36	16600036	4*10 Screw
37	16600037	Ø6*60 Sub hood connection pin
38	16600038	Saw blade
39	16600039	4*14 Screw
40	16600040	Water nozzle left
41	16600041	Ø8*Ø12*2 O-RING
42	16600042	M4*18 Three-piece set screws
43	16600043	M4*14 Three-piece set screws
44	16600044	Inlet bracket left
45	16600045	M6*8 Screw
46	16600046	Water nozzle right
47	16600047	Water inlet bracket right
48	16600048	Locating guide post
49	16600049	Guide post brass sleeve
50	16600050	Lower protective cover



S. N.	Part Code	Parts Name
51	16600051	Lower the wheel cover
52	16600052	M4*14 Three-piece set of screws
53	16600053	1/4 Quick connection pipe
54	16600054	M8 Screw nut
55	16600055	Press the wheel and the plate
56	16600056	Lower press wheel
57	16600057	Ø18*Ø32*7 Framework oil seal
58	16600058	Lower wheel drive shaft
59	16600059	Ø32 Inside spring pliers
60	16600060	6201 Bearing
61	16600061	6200 Bearing
62	16600062	M8 Screw nut
63	16600063	Ø26*Ø2.2 O-RING
64	16600064	M32 End cap
65	16600065	Baffle pin
66	16600066	Pressure Spring
67	16600067	Board
68	16600068	Baffle hook
69	16600069	M6*16 Screw
70	16600070	Ø8*Ø16*1 Gasket
71	16600071	Ø8 Outer spring pliers
72	16600072	M8*20 Screw
73	16600073	Ø8*Ø24*3 Gasket
74	16600074	Driving wheel
75	16600075	Ø22*Ø39*0.3 Gasket
76	16600076	Output shaft
77	16600077	Front cover
78	16600078	M4*25 Screw
79	16600079	M5*20 Screw
80	16600080	Adjustment screw

S. N.	Part Code	Parts Name
81	16600081	16*26H Flat spring
82	16600082	Adjusting spacer
83	16600083	Ø8*30*M6*L Screw
84	16600084	Lead screw nut sleeve
85	16600085	Right Angle iron
86	16600086	M4*10 Screw
87	16600087	M5*12 Screw
88	16600088	Ø14*Ø25*2 Rubber gasket
89	16600089	Ø13.3*Ø24*2 Iron gasket
90	16600090	25*25 Yellow flat spring
91	16600091	Drive wheel adjusting hand wheel
92	16600092	4.2*35 Split pin
93	16600093	Ø35*Ø20*7 Framework oil seal
94	16600094	6203 Bearing
95	16600095	Ø40 Inside spring pliers
96	16600096	Ø17*Ø21*37 Gear limit
97	16600097	aluminum sleeve
98	16600098	4*10 Key
99	16600099	Middle Gear
100	16600100	Ø17 Outer spring pliers
101	16600101	6201 Bearing
102	16600102	6000 Bearing
103	16600103	Driving Shaft
104	16600104	4*20 Key
105	16600105	Big bevel gear
106	16600106	Big gear
107	16600107	6201 Bearing
108	16600108	Head housing
109	16600109	M5*35 Hexagon single spring washer screws



S. N.	Part Code	Parts Name	S. N.	Part Code	Parts Name
110	16600110	M5*35 Hex socket three-piece set screws	126	16600126	Controller
111	16600111	N7 Screw nut	127	16600127	Switch button
112	16600112	Small gear	128	16600128	Switch button seat
113	16600113	6301 Bearing	129	16600129	Cable ramp
114	16600114	Bearing cover	130	16600130	Protecting bush
115	16600115	M5*14 Three-piece set screws	131	16600131	Power cord
116	16600116	Ø12*Ø1.5 Stainless gasket	132	16600132	Switch handle-Right cover
117	16600117	Ø9*Ø0.3 Stainless gasket	133	16600133	4*50 Screw
118	16600118	629 Bearing	134	16600134	4*16 Screw
119	16600119	Wind shield	135	16600135	Water pipe set [®]
120	16600120	5*85 Screw	136	16600136	Iron bend handle
121	16600121	Stator	137	16600137	M10*16 Screw
122	16600122	Ø26*Ø30*10.1 Aluminum bearing seat	138	16600138	Drive wheel wrench
123	16600123	Housing	139	16600139	Drive wheel wrench
124	16600124	M5*35 Hex socket three-piece set screws	140	16600140	13 Socket wrench
125	16600125	Switch handle-Left cover			