






S. N.	Part Code	Parts Name
1	8140001	Rubber head
2	8140002	Ring
3	8140003	Ring
4	8140004	Stell ball holder
5	8140005	Ball holder spring
6	8140006	Sleeve
7	8140007	Ring
8	8140008	Screw
9	8140009	Spring washer
10	8140010	Head strong
11	8140011	Ball
12	8140012	Teleflex
13	8140013	O ring
14	8140014	Impact hammer
15	8140015	Ring
16	8140016	Buffer ring
17	8140017	O ring
18	8140018	O ring
19	8140019	Cylinder
20	8140020	Cylinder ring
21	8140021	Screw
22	8140022	Washer
23	8140023	Cylinder case
24	8140024	Paper washer
25	8140025	Hammer
26	8140026	O ring
27	8140027	Piston pin
28	8140028	Piston
29	8140029	Needling bearing
30	8140030	Connecting rod

S. N.	Part Code	Parts Name
31	8140031	Oil cover
32	8140032	O ring
33	8140033	Eccentric shaft
34	8140034	Semi-round key
35	8140035	Ring
36	8140036	Bearing 6303
37	8140037	O ring
38	8140038	Gear box
39	8140039	Position sleeve
40	8140040	Oil seal
41	8140041	Gear
42	8140042	Bearing 6001
43	8140043	Inner cover
44	8140044	Anti-oil washer
45	8140045	Bearing 6201
46	8140046	Washer
47	8140047	Rotor
48	8140048	Bearing 608
49	8140049	Fan guid
50	8140050	Self screw
51	8140051	Stator
52	8140052	Tension spring
53	8140053	Motor
54	8140054	Washer
55	8140055	Spring washer
56	8140056	Screw
57	8140057	Brush holder
58	8140058	Carbon brushes
59	8140059	Brush holder cover
60	8140060	Back cover



S. N.	Part Code	Parts Name
61	8140061	Self screw
62	8140062	Handle
63	8140063	Screw
64	8140064	Screw
65	8140065	Switch
66	8140066	Handle
67	8140067	Self screw
68	8140068	Capacitance
69	8140069	Inductance

S. N.	Part Code	Parts Name
70	8140070	Cable board
71	8140071	Cable cover
72	8140072	Cable
73	8140073	Screw
74	8140074	Rotating seat
75	8140075	Clamp seat
76	8140076	Hoop
77	8140077	Auxiliary handle
78	8140078	Knob